

# DISMANTLING THE GSG-522 TRIGGER GROUP



1. Unscrew the safety lever.



2. Remove the safety lever.



3. Unscrew the cover of the frame.



4. Remove the cover of the frame.



5. Unscrew the inside allen screw in order to remove the trigger group.



6. For changing the frame please follow the steps backwards.

# CHANGING THE GSG-522 COCKING TUBE



1. Unscrew the screws as shown.



2. Unscrew the cocking lever.



3. Take out the cocking lever first and then the inner tube.



4. For changing the cocking tube, please follow the steps backwards.



GERMAN SPORT GUNS  
GERMAN SPORT GUNS GMBH  
OESTERWEG 21  
D-59469 ENSE-HÖINGEN  
WWW.GSG-522.DE  
INFO@GERMANSPORTGUNS.DE

TEL.: +49 (0) 2938 97837-0  
FAX: +49 (0) 2938 97837-130